

# Fast Trak Display 4' and 6'

146011, 146012, 146081, 146084  
146014, 146015, 146082, 146085

## Product Parts

- 1 - Display
- 2 - Header
- 3 - Header Connector




## Display Set-Up

### Step 1

Remove all parts from the carry case and place on a clean, flat surface along with your graphic panels.

### Step 2

Unfold the panels of the Display (1) until the unit lays flat on your surface. Place each graphic panel, with Hook side down, to connect to the Velcro® receptive panels.



Repeat for the Header (2).


### Step 3

Stand the unit upright on a table and move side panels to approximately 30 degree angles.



### Step 4

Attach the Header Connector (3) to the bottom of the Header (2)




### Step 5

Push the Header Connector (3) down to attach the Header (2) to the center panel on the Display (1).



## Storage

Place all product parts into Carry Case and store in a cool, dry location.



## Care

Spot clean with a damp cloth.

*Warranty Information: All products are designed to provide the user with a cost-effective and durable product. Standard warranty is a 'one year parts and labor' warranty which warrants product against defects in material and workmanship. It does not cover damage due to accidents, abuse, or normal wear and tear. Products found to be defective will be replaced or repaired at factory's discretion.*